




Set-up




Volume




Vario settings




Installation



Weak lift buzzer (during flight)




Sink alarm settings



ON / OFF

Searching GPS*



ON : 3 sec.

OFF : 3 sec.


Battery level:

3x


2x

1x

Low battery:



Voice: Manual mode



Voice: Auto mode (during flight)

